



Order book

This module allows to manage an **order book** for your **whole sites**.

It allows to plan **monthly** your **production load** for the following months. Indicating your **critical** load limit, you can **anticipate** the **low** and **high** production to **act** accordingly.

Entering an order

Estimated weight:
 Assembled: **500000** Cut and bent: **500000** Straight: **0**
 Delivered weight:
 Assembled: **218** Cut and bent + length: **356**
 Weight ASS not planned: **0 (0%)** Weight CB + CL not planned: **0 (0%)**

		January 2009	February 2009	March 2009	April 2009	May 2009
ASS	Kg					
	%					
CB + CL	Kg					
	%					

Percentage | Chart ASS | Chart CB + CL | Chart TOTAL

ASS :

CB + CL :

TOTAL :

Legend:
 Part of the site finished
 Part of the site do to in the cor
 Part of the site to do this month
 Part of the site finished (advan

Site monitoring management

Begin month: September 2009 End month: March 2010 Planned weight by period

ASSEMBLED Planned weight sum (not delivered) (Kg): 1942433 average of the period (Kg): 165000 Print

CUT AND BENT + LENGTH Planned weight sum (not delivered) (Kg): 1902336 average of the period (Kg): 224027 Print

TOTAL Planned weight sum (not delivered) (Kg): 3844769 average of the period (Kg): 389027 Print

Legend:
 : Previous months : Advance : Work to do : Average weight of the period

General Data / Invoicing parameters

Percentage | Chart ASS | Chart CB + CL

Legend:
 : Previous months : Advance : Work to do

Planning of all sites

Total load on one site